



AFFORDABLE PARTY HIRE ★ 0434 509 111

POPCORN MACHINE

HOW TO USE IT

⚠ BEFORE YOU START

Plug into a **240-volt dedicated circuit**

Kettle motor **OFF** when not popping

The kettle gets **VERY HOT** – use caution

NEVER put water on the kettle

1 · MAKING POPCORN

- 1 Plug in the machine and push the kettle lid up to the top of the cabinet – a magnet holds it in place.
- 2 Turn the HEAT and LIGHT switches ON. Wait 3–4 minutes for the kettle to heat up.
- 3 Turn the KETTLE MOTOR switch ON to start the motor.
- 4 Add a small squirt of oil into the kettle, then immediately add $\frac{3}{4}$ cup of popcorn.
- 5 Pull the kettle lid down from the top of the cabinet to cover the kettle.
- 6 While the corn pops, open the plexiglass doors slightly to prevent fogging.
- 7 When the popping stops, turn BOTH the kettle HEAT and MOTOR switches OFF.
- 8 Lift the lid back up to the magnet. Dump the popcorn by releasing the kettle: rotate the black handle clockwise and pull downward.
- 9 Re-hook the kettle onto the holding bolt using the black handle. CAUTION – the kettle is very hot!
- 10 Repeat for more batches – no need to wait, the kettle stays pre-heated. Keep the HEATING LIGHT ON to keep popcorn warm.

⚠ **NEVER** leave the kettle uncovered while popping – oil and popcorn will spray all over the machine!

PER BATCH

$\frac{3}{4}$ cup

POPCORN

small

SQUIRT OF OIL

Heat-up time: 3–4 min (first batch only)

2 · CLEANING

- 1 Wait at least one hour for the kettle to cool completely – it stays very hot.
- 2 Wipe all oil off the inside and outside of the kettle with a DRY, clean, soft cloth.
- 3 **NEVER** put water on the kettle!

\$25 fee

if the machine comes back unwiped or not emptied. Please return it clean!

Questions or problems? Call us on 0434 509 111 – enjoy your popcorn! 🍿